

DIGI-SHOT M

Waterproof camera bag with flap and zip



Carrying handle

Abrasion resistant Cordura

Waterproof zipper

Fixing for shoulder strap

Flap with quick release

Mesh pockets (on both sides) with Velcro

Stable bottom

Removable padded shoulder strap



main compartment



Loop for opening of zipper

Belt loops



Application example for Digi-Shot M: DSLR camera with zoom lens, two further lenses, battery and memory card (contents not included)

Size	Height cm/in.	Width cm/in.	Depth cm/in.	Vol. l/cu.in.	Weight g/oz.
M	18.5/	23.5/9.3	13.5/5.3	5.9360	721/25.4

- Stable waterproof shoulder bag for extensive camera equipment
- Reliable protection of rain and spray
- Main compartment with waterproof zip
- Two lateral outer mesh pockets (not waterproof) with Velcro
- Quick release buckles on flap allow quick access to main compartment
- PU-coated Cordura fabric
- Carrying handle
- Flexible, individually adjustable pads
- Internal mesh pockets (not waterproof) inside flap for memory cards, filter, batteries etc.
- Padded, removable shoulder strap fixed with snap hooks
- Features of size M: D-rings for fixing the ORTLIEB camera carrying system (optional accessory art. code P15)
- Size M suitable for larger SLR cameras with zoom lens and two further lenses (wide angle to standard)

Bag is supplied with shoulder strap

PRODUCT-INFO

Please find information on IP symbols on our info sheet or at www.ortlieb.com/ip-symbols

Digi-Shot_M_12_2012

DIGI-SHOT L



Waterproof camera bag with flap and zip



- Carrying handle
- Abrasion resistant Cordura
- Waterproof zipper
- Fixing for shoulder strap
- Flap with quick release
- Mesh pockets (on both sides) with Velcro
- Loops for fixing tripod
- Stable bottom
- Removable padded shoulder strap



main compartment



- Loop for opening of zipper
- Belt loops



Application example for Digi-Shot L: DSLR camera with zoom lens, one further housing, three further lenses, battery and memory card (contents not included)

Size	Height cm/in.	Width cm/in.	Depth cm/in.	Vol. l/cu.in.	Weight g/oz.
L	22.5/8.9	27.5/10.8	17.5/6.9	10.8/659	921/32.4

- Large, stable waterproof shoulder bag for extensive camera equipment
- Reliable protection of rain and spray
- Main compartment with waterproof zip
- Two lateral outer mesh pockets (not waterproof) with Velcro
- Quick release buckles on flap allow quick access to main compartment
- PU-coated Cordura fabric
- Carrying handle
- Flexible, individually adjustable pads
- Inner mesh pockets (not waterproof) inside flap for memory cards, filter, batteries etc.
- Padded, removable shoulder strap fixed with snap hooks
- Features size L only: inner pockets in main compartment lid, loops for fixing tripod
- Size M suitable for larger SLR cameras with zoom lens and two further lenses (wide angle to standard)

Bag is supplied with shoulder strap

PRODUCT-INFO

Please find information on IP symbols on our info sheet or at www.ortlieb.com/ip-symbols

Digi_Shot_L_12_2012